



Model number

AS-Interface Power Calculator

AS-Interface Power supply and network checking utility

Features

- Straightforward operation
- Checks to make sure AS-i network configuration is Okay
- Calculates Voltage drop of AS-i cable
- Calculates AS-i and Auxiliary power supply load

Technical data

General specifications

Description	Software to help users choose the correct power supply, check voltage drop is not too large, and verify the configuration of an AS-Interface network
-------------	--

System requirements

Hardware requirements	Intel® Pentium® III processor or better 20 GB of available hard disk memory 521 MB RAM CD-ROM or DVD drive Serial interface on PC
Operating system	Microsoft Windows Win 98 SE, Win Me, Win 2000, Win XP, NT4, Vista 32 Bit